

## Product Care

Be sure to always carry out product care after use to ensure long life of the product.

- To perform product care, use a mild dish detergent diluted with lukewarm water.
- If not using the product for a long period of time, wash clean of impurities, then dry thoroughly.

### Main unit

- ① If extra dirty, soak a soft cloth in neutral dish detergent diluted with lukewarm water, wring it out thoroughly, and wipe clean.  
(Do not use alkaline or orange oil based detergents.)
- ② Wipe thoroughly with a dry cloth.
- ③ Do not "set to soak" or place the product in boiling water.  
\* Caution: Never use an automatic dishwasher or dish dryer.
- ④ Do not use chlorine bleach.

### Inner bottle


- ① For each use, wipe clean with a soft sponge, then dry thoroughly.
- ② Although this product is made of stainless steel, water qualities or impurities may cause red, rust-like spots to appear in some cases. In such a case, pour in hot water with about 10% vinegar and keep it in for 30 minutes, then use a soft brush to clean out the inside, and rinse thoroughly.  
\* Be sure to clean and thoroughly dry before storage.

## User Manual

### STCV2 Vacuum-Sealed Stainless Cup

#### STCV2

**Convenience store coffee  
Hot mediumsize  
Hot large size, too  
Iced small, medium, and  
large sizes**



## Carry out product care as follows to prevent burns, change in beverage quality/color, product malfunction, or contamination.

[Read before use] ● Before using this product, be sure to wash the inner bottle and its various parts in lukewarm water, then dry thoroughly. ● To prevent the spread of odors, wash each part in lukewarm water, and dry thoroughly before storage.

[Usage Precautions] ● Do not place near flames or heat up directly. Doing so may deform or damage the product. ● Pouring in a hot beverage may cause you to burn yourself, so be sure it has cooled to a temperature sufficient for drinking before consumption. ● Do not subject to significant shock. ● Do not heat up in the microwave. ● Never store in the freezer. Doing so could cause damage. ● Never "set to soak" when washing. Doing so could cause rust. Use a mild dish detergent diluted with hot water and sponge to wash, then wipe dry. ● Do not sanitize in boiling water. Doing so may deform or damage the product. ● Never clean with an automatic dishwasher or dryer. ● Do not polish with a scrub brush or polishing powder. ● Please refrain from using alkaline detergent or orange oil detergent, as it could cause the pattern/design to peel off, or result in discoloration. ● If the product is cracked or chipped, immediately refrain from use. ● Do not fill with dry ice. ● Do not store in direct sunlight for a long period of time. ● Do not allow infants or toddlers to play with this product. ● Storing in high temperatures while the outer pattern/design is oily may cause peeling. Also, refrain from soaking in hot, oily water.

● Please refrain from using this product while driving. ● Please note that cups of certain shapes and sizes may not fit inside the unit. ● No compensation shall be made for damage as a result of product misuse.

#### Precautions when pouring a beverage, etc. directly into the unit

- When filling the unit with liquid high in sodium content, such as miso soup, other soups, or sports drinks, thoroughly rinse it out with water immediately after use, and perform product care.

#### When placing a coffee cup, etc. inside the unit

- When placing a beverage-filled cup inside the unit for use, be careful not to tilt it too far in either direction. Over-tilting may cause the contents to leak out, causing burns or soiling of clothing, etc.
- When placing a coffee cup, etc. inside the unit for use, closing the lid will retain hot/cold temperature for a longer period of time.