

### Cautions


- Peel away transparent protective film from surface before use.
- There is no protective covering, so do not insert anything that may cause damage.
- Do not use the suitcase as a seat.
- Please be mindful of people and objects in the surrounding area when moving forward. In the rare case of trouble such as an accident or damage, our company will not be held responsible.
- Avoid operation on uneven surfaces.
- Be careful not to get your fingers caught when raising or lowering the handle.
- Do not lean against this product, as it could be dangerous.
- This product includes small parts, so be cautious that they are not accidentally swallowed.
- Carry valuables, cash, etc. on your person for safety.
- Some parts of this product are made of PVC.
- Due to the product's mirror finish, small scratches are unavoidable during the manufacturing process. Please also note that dust or other particles may adhere to the design surface due to static electricity.
- Load capacity: 18 kg (approx. 40 lbs)
- Do not fill the product above its load capacity.
- Size (external dimensions): Approx. 56 x 38 x 22 cm (22 x 15 x 9 in)  
\* Size is measured from casters to the tip of the handle.
- Volume: Approx. 31 L
- Please note that "suitcase sizes allowed as carry-ons," and "baggage checked at the counter not requiring additional payment" differ according to each airline company. For details, please check with the airline you intend to travel with.
- After creating your password, be sure to write it down so you do not forget it.
- If you are covered by travel insurance and experience damage (excluding intentional damage, scuffs, scrapes, or soiling) you should contact the applicable insurance company for assistance. If your suitcase is damaged while under the care of an airline company, you should promptly contact that company for assistance after retrieving their baggage.

### Storage

- If the surface is dirty, wipe it clean with a cloth slightly-dampened with neutral detergent. (Do not use volatile substances such as benzine. Doing so could cause damage.)
- After removing dirt and drying away from direct sunlight, store in a well-ventilated area.

Equipped with four caster wheels for smooth,  
360° mobility in any direction!

## TSA LOCK® INCLUDED



### How to set the TSA Combination Lock

The default combination is set to 0-0-0.

To set your own combination, perform the following steps.

1. Set the dials (B) to the combination of numbers needed to open the lock. (Default is set to 0-0-0.)
2. Use a pointed object to press the Reset Button (A) until you hear a click.
3. Turn the dials (B) to your desired combination of numbers. (Example: 8-8-8)
4. Press the Unlock Button (C) in the direction of the arrow. Once you hear a click, the Reset Button will return to its initial position, and the combination is set.

\* To set a new combination, repeat the steps above.


\* So as not to forget your set combination, be sure to write it in the space provided below, and store it in a safe place for future reference.

|  |  |  |
|--|--|--|
|  |  |  |
|--|--|--|

\* The Master Cylinder is not for your use. It is a keyhole exclusively for use by TSA employees with a special tool.


### How to Use

1. Once you have set a combination, push the two catches into the holder as shown in the illustration.



2. To lock, scramble the numbers on the dial.

3. To unlock, align the set combination numbers, then press the Unlock Button (C) in the direction of the arrow to release the catches from the fastener.



### Cautions

If the combination is set incorrectly or forgotten, this lock may be rendered unusable. Please use with care.

